



### NOTE:

- 1 - SOLID MOUNT ONE END
- 2 - DO NOT SIDE LOAD FREE END

## PROPER USE AND MOUNTING INSTRUCTIONS

1. Position 005 swivel in a vise.
2. Connect hoses to the swivel using Teflon tape.
  - Do not use rigid piping as this will compromise the life of the union.
  - The hose should be flexible and have a slight bend.
    - Extreme bends can reduce the flexibility of the hose.
  - The rubber hose selected should be able to safely handle the working pressure.
  - The hose should be properly supported & should not side load the union.

